



# HP G60T-600 CTO Battery Removal

This guide will show you how to remove your device's battery. You will need to perform this step at the beginning of all the replacement guides for this device.

Written By: Dominic DeSantis



## INTRODUCTION

Remove the battery from your device.

## Step 1 — Battery



⚠ Failure to remove the battery before performing any replacement guide may result in electric shock.

- Close your device, then turn it over.

## Step 2



- Place your index finger on the ridged tab.



## Step 3



- Apply moderate pressure to the tab and slide it to the right.
- While the tab is on the right, you should be able to gently slide your battery out of your device.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 05:54:04 PM.